



Made in Eugene, Oregon











is committed to using sustainable packaging materials that can be recovered and recycled to make new products.

conscious suppliers and source locally



Visit us online at: downtoearthfertilizer.com

ormation regarding the contents and levels of metals in this product is available on the internet at: ttp://www.aapfco.org/metals.html



A 720 MITTE is a natural mineral product mined in central Utah. This unique deposit was formed when an ancient volcano erupted and its ash settled into a prehistoric seabed creating a complex mineral composition. AZOMITE provides essential minerals key to green growth and proper stem and fruit development. This powder grade is ideal for direct application or for blending with other fertilizer materials, amendments, composts or manures to help meet plant nutritional needs.

GUARANTEED ANALYSIS

SOLUBLE POTASH (K2O) 0.2% Derived from: Volcanic Ash CALCIUM (Ca) MAGNESIUM (Mg) 0.5% 0.001% Water Soluble Magnesium

1.8% Listed by the Organic Materials Review Institute (OMRI) for use in organic production. F002174

0.1%

APPLICATION RATES

Approximate Conversions: 1% cups = 1 lb % cup = 2.5 oz 1 Tbsp = 0.5 oz

Vegetable Gardens

SODIUM (Na)

To prepare new gardens, apply 1-2 lbs per 10 square feet and thoroughly mix into the top 3" of soil in spring or fall.

For new transplants, add 1-2 tsp per hole, mix into soil and water in well.

When adding to finished compost, add 11/2 Tbsp per gallon of compost and mix thoroughly. Allow to rest for 1-2 weeks before application to plants, soil, or containers. For larger projects, add 10 lbs per

yard of finished compost. For new compost piles, thoroughly

incorporate 10 lbs of AZOMITE per yard of fresh (uncomposted) material.

Containers:

For new plantings, add 1-2 Tbsp per gallon of soil and mix thoroughly OR add 1/2-1 lb per cubic yard.

For established plants, lightly mix 1-2 tsp per gallon of soil into the soil surface every other month during the growing season.

Trees, Shrubs & Vines:

Spread 1 lb per 2" of trunk diameter around the base outwards to the drip line, mix into soil surface and water in well.

For grapes, apply 1/4-1 lb around each plant and thoroughly mix into soil. For new trees, prepare transplant hole and mix 4-8 oz with the backfill

soil. Use the amended soil to fill in around the new tree and water in well.







